



LA Fixed_speed side_discharge

Service Manual

New Released

Form: MYFETM-MOW1-190830

PAC Fixed_speed R410a 60Hz Cooling only SERIES

YEFE(18-60)BZTM-MOW1
YEFE(36-60)BZSM-MOW1
YFFE(18-60)BZTM-MOR1
YFFE(36-60)BZSM-MOR1
YKFE(18-60)BZTM-MOR1
YKFE(36-60)BZSM-MOR1



Issue Date
Aug 30, 2019

Table of Contents

Page

1. Safety Precautions	1
1. In case of Accidents or Emergency	
2. Pre-Installation and Installation	
3. Operation and Maintenance	
2. Specifications	3
1. Model Reference	
2. Electrical Wiring Diagrams	
3. Product Features	20
1. Operation Modes and Functions	
4. Maintenance and Disassembly	25
1. Maintenance	
2. Disassembly	
5. Troubleshooting	82
1. Safety Caution	
2. General Troubleshooting	
3. Error Diagnosis and Troubleshooting Without Error Code	
4. Quick Maintenance by Error Code	
5. Troubleshooting by Error Code	
Appendix	106
i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)	
ii) Pressure On Service Port	

Safety Precautions

Contents

1.	In Case of Accidents or Emergency	2
2.	Pre-Installation.....	2
3.	Operation and Maintenance.....	2

To prevent personal injury, or property or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.

! **WARNING** indicates a potentially hazardous situation which if not avoided could result in serious personal injury, or death.

! **CAUTION** indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

1. In case of Accidents or Emergency

! **WARNING**

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.

! **CAUTION**

- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

2. Pre-Installation and Installation

! **WARNING**

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized Midea service center.

! **CAUTION**

- While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

3. Operation and Maintenance

! **WARNING**

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- Avoid direct skin contact with water drained from the unit.
- Use a firm stool or step ladder according to manufacturer procedures when cleaning or maintaining the unit.

! **CAUTION**

- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecure location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge created by the outdoor unit will negatively impact the environment or nearby residences.
- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit operates in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

Specifications

Contents

1.	Model Reference.....	4
2.	Electrical Wiring Diagrams.....	6
2.1	Indoor Unit.....	6
2.2	Outdoor Unit.....	12

1. Model Reference

Refer to the following table to determine the specific indoor and outdoor unit model number of your purchased equipment.


Outdoor Unit Model	Indoor Unit Model	Capacity (Btu)	Power Supply
YUFE18BYTM-MO-X	YFFE18BXTM-M-R1	18k	1 ϕ , 220-230V~, 60Hz
	YKFE18BXTM-M-R1		
	YEFE18BXTM-M-W1		
YUFE24BYTM-MO-X	YFFE24BXTM-M-R1	24k	1 ϕ , 220-230V~, 60Hz
	YKFE24BXTM-M-R1		
	YEFE24BXTM-M-W1		
YUFE36BYTM-MO-X	YFFE36BXTM-M-R1	36k	1 ϕ , 220-230V~, 60Hz
	YKFE36BXTM-M-R1		
	YEFE36BXTM-M-W1		
YUFE36BYSM-MO-1	YFFE36BXTM-M-R1	36k	3 ϕ , 220V~, 60Hz
	YKFE36BXTM-M-R1		
	YEFE36BXTM-M-W1		
YUFE48BYTM-MS-1	YFFE48BXTM-M-R1	48k	1 ϕ , 220-230V~, 60Hz
	YKFE48BXTM-M-R1		
	YEFE48BXTM-M-W1		
YUFE48BYSM-MS-1	YFFE48BXTM-M-R1	48k	3 ϕ , 220V~, 60Hz
	YKFE48BXTM-M-R1		
	YEFE48BXTM-M-W1		
YUFE60BYTM-MS-1	YFFE60BXTM-M-R1	60k	1 ϕ , 220-230V~, 60Hz
	YKFE60BXTM-M-R1		
	YEFE60BXTM-M-W1		
YUFE60BYSM-MS-1	YFFE60BXTM-M-R1	60k	3 ϕ , 220V~, 60Hz
	YKFE60BXTM-M-R1		
	YEFE60BXTM-M-W1		

2. Electrical Wiring Diagrams


2.1 Indoor unit

Abbreviation	Paraphrase
Y/G	Yellow-Green Conductor
CAP1	Indoor Fan Capacitor
FAN1, FAN2	Indoor Fan
K3	Water Level Switch
M	Swing Motor
PUMP	PUMP
L	LIVE
N	NEUTRAL
TO CCM Comm.Bus	Central Controller
RT1, T1	Indoor Room Temperature
RT2, T2	Coil Temperature of Indoor Heat Exchanger
P1	Super High Speed
P2	High Speed
T3, T4, T5	Transformer
GM1, GM3	Horizontal Swing Motor
GM2	Vertical Swing Motor
AC FAN	Alternating Current Fan
DC FAN	Director Current Fan


YFFE18BXTM-M-R1, YFFE24BXTM-M-R1, YFFE36BXTM-M-R1, YFFE48BXTM-M-R1, YFFE60BXTM-M-R1




YKFE18BXTM-M-R1, YKFE24BXTM-M-R1, YKFE36BXTM-M-R1, YKFE48BXTM-M-R1



YEFE18BXTM-M-W1, YEFE24BXTM-M-W1, YEFE48BXTM-M-W1, YEFE60BXTM-M-W1, YEFE18BXTM-M-W1, YEFE24BXTM-M-W1, YEFE48BXTM-M-W1, YEFE60BXTM-M-W1




YEFE36BXTM-M-W1, YEFE36BXTM-M-W1



16022500000850


INDOOR WIRING DIAGRAM



CODE	NAME
CAP1	INDOOR FAN CAPACITOR
CN1-66	P. C. B SOCKETS
FAN1	INDOOR FAN
K3	WATER LEVEL SWITCH
M	SWING MOTOR
PUMP	PUMP
RT1	ROOM TEMP. SENSOR
RT2	PIPE TEMP. SENSOR
XP3-XP8	CONNECTOR
XS3-XS8	CONNECTOR
P1	SUPER HIGH SPEED
P2	HIGH SPEED
T3	TRANSFORMER


NOTE: FOR FAN OPERATES IN SUPER HIGH SPEED, PLEASE SWITCH HIGH SPEED TO SUPER HIGH SPEED, SEE FAN-WIRING PART FOR DETAIL INFORMATION!



For all models:




2.2 Outdoor Unit

Abbreviation	Paraphrase
CAP1, CAP2, CAP3,CAP4	Capacitor
FAN	Outdoor Fan Motor
KM8	Contactora
CT1, CT2	AC Current Detector
COMP	Compressor
L-PRO, K2	Low Pressure Switch/Shorting Stub
K1	High Pressure Switch/Shorting Stub
TRANS	Power Transformer
T4	10KΩ RESISTANCE/Outdoor Ambient Temperature
T3	10KΩ RESISTANCE/Coil Temperature of Condenser
XT1	2-Way Terminal/4-Way Terminal
XT2	3-Way Terminal
XT4	Terminal
K3	Compressor Discharge Temperature/Shorting Stub
R1	Resistance
XP1~XP5,XS1~XS5	Connectors





YUFE48BYTM-MS-1




WIRING DIAGRAM
(OUTDOOR UNIT)

CODE	PART NAME
COMP	COMPRESSOR
FAN UP FAN_DOWN	OUTDOOR FAN
CAP3 CAP4	FAN CAP.
KM1	AC CONTACTOR
XT5-6	CONNECTOR
H/L-PRO	HIGH/LOW PRESSURE SWITCH
RT3	PIPE TEMP. SENSOR
XS7-9	CONNECTORS
XP7-9	CONNECTORS
CN100-208	P.C.BOARD SOCKETS
K1	TEMP. PROTECT SWITCH
T5	TRANSFORMER
CT1	CURRENT DETECTOR
CAP2	COMPRESSOR CAP.

16022500001328

YUFE48BYSM-MS-1





WIRING DIAGRAM
(OUTDOOR UNIT)

CODE	PART NAME
COMP	COMPRESSOR
FAN UP FAN_DOWN	OUTDOOR FAN
CAP3 CAP4	FAN CAP.
KM1	AC CONTACTOR
XT5-6	CONNECTOR
H-PRO	HIGH PRESSURE SWITCH / SHORTING STUB
T3	10K RESISTANCE / PIPE TEMP. SENSOR
XS7-9	CONNECTORS
XP7-9	CONNECTORS
CN100-208	P.C.BOARD SOCKETS
K1	TEMP. PROTECT SWITCH / SHORTING STUB
T5	TRANSFORMER
CT1	CURRENT DETECTOR
L-PRO	LOW PRESSURE SWITCH / SHORTING STUB
T4	10K RESISTANCE / ROOM TEMP. SENSOR

202075790237

16022700001387



1. Operation Modes and Functions

1.1 Abbreviation

Unit element abbreviations

Abbreviation	Element
T1	Indoor room temperature
T2	Coil temperature of evaporator
T3	Coil temperature of condenser
T4	Outdoor ambient temperature
TS	Set temperature

1.2 Safety Features

Compressor Three-minute Delay at Restart

Compressor functions are delayed for up to one minute upon the first startup of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

Phase Check Function(for 3 phase models)

If the phase sequence is detected wrong or lack of 1 or 2 phase, the unit won't start and there is error code displayed on outdoor PCB.

Low Pressure Check Function(for 48k and 60k models)

The low pressure switch should be always closed. If it is open, the system will stop until the fault is cleared. During defrosting procedure, 4 minutes after defrosting ends and 5 minutes after compressor is on in heating mode, low pressure switch won't be checked.

Note: The system will not check if the protection could be cleared in 30 seconds after the protection occurs. If this protection occurs 3 times, it won't recover automatically until the main power is cut off.

Over-current Protection

When compressor is running, if the current is over twice of the rated for 3 seconds, the compressor will stop and an error code will be displayed on the outdoor PCB. If the current becomes normal, the compressor will restart after 3 minutes.

Note: The current won't be checked within 3 seconds after the compressor starts. The system will not check if the protection could be cleared in 30 seconds after the protection occurs.

Sensor redundancy and automatic shutoff

- If any one of temperature sensor malfunctions, the air conditioner displays the corresponding error code and ceases operation.

Refrigerant leakage detection

This function is active only when cooling mode is selected. It will detect if the compressor is being damaged by refrigerant leakage or by compressor overload. This is measured using the coil temperature of evaporator T2 when the compressor is in operation.

1.3 Display Function


Unit display functions

Ceiling&floor


Product Features

Contents


1.	Operation Modes and Functions	21
1.1	Abbreviation.....	21
1.2	Safety Features	21
1.3	Display Function	21
1.4	Fan Mode.....	22
1.5	Cooling Mode	22
1.6	Auto-mode.....	22
1.7	Drying Mode	22
1.8	Timer Function	22
1.9	Sleep Function.....	22
1.10	Auto-Restart Function.....	23
1.11	Refrigerant Leakage Detection.....	23
1.12	Follow Me(Optional).....	23
1.13	Drain Pump Control (For Duct and Cassette).....	24




A6 Duct



Super-slim Cassette



Super-slim Cassette (with an auto-lifting panel)



1.4 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to high, medium, low, or auto.
- The lower operations are identical to those in cooling mode.

1.5 Cooling Mode

1.5.1 Compressor Control

When indoor room temperature T1 is lower than setting value, the compressor and outdoor fan cease operation.

1.5.2 Indoor Fan Control

In cooling mode, the indoor fan operates continuously. The fan speed can be set to high, medium, low or auto.

1.5.3 Outdoor Fan Control

The On-off outdoor units have single fan speed. The outdoor fan runs following the compressor except when AC is in evaporator high temperature protection in heating mode, condenser high temperature protection in cooling mode, defrosting mode and the current protection.

1.5.4 Evaporator Temperature Protection

When evaporator temperature drops below a configured value for some time, the compressor and outdoor fan cease operations.

1.6 Heating Mode (for heat pump models)

1.6.1 Compressor Control

When indoor room temp. T1 is higher than setting value the compressor and outdoor fan will shut off.

1.6.2 Indoor Fan Control

- When the compressor is on, the indoor fan can be set to high/med/low/auto. And the anti-cold wind function has the priority.
- The indoor fan speed will adjust according to the value of T1-TS.

1.6.3 Outdoor Fan Control

For on-off models, outdoor units just have one single fan speed. The operation of outdoor fan is consistent with the

operation of compressor, except the following situations.

- High temperature protection of evaporator
- Defrosting
- Current protection

1.6.4 Defrosting mode

- The unit enters defrosting mode according to changes in the temperature value of T3.
- If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
 - Unit runs for 10 minutes consecutively in defrosting mode.
 - $T3 \geq TE18$ or other setting value.
 - AC is turned off, or other mode is set.

1.7 Auto-mode

- This mode can be selected with the remote controller and the setting temperature can be changed between 17°C~30°C.
- In auto mode, the machine selects cooling, heating, or fan-only mode on the basis of ΔT ($\Delta T = T1 - Ts$).

ΔT	Running mode
$\Delta T > 2\text{ }^{\circ}\text{C}$	Cooling
$-3\text{ }^{\circ}\text{C} \leq \Delta T \leq 2\text{ }^{\circ}\text{C}$	Fan-only
$\Delta T < -3\text{ }^{\circ}\text{C}$	Heating*

- The louver operates same as in relevant mode.
- If the machine changes running mode to auto mode, it will choose running mode again.
- If the machine switches mode between heating and cooling, the compressor will keep stopping for certain time and then choose running mode according to T1-Ts.
- If the setting temperature is modified, the machine will choose running mode again.

1.8 Drying mode

- Indoor fan speed is fixed at breeze and can't be changed. The louver angle is the same as in cooling mode.
- All protections are active and the same as that in cooling mode.

1.9 Timer Function

- The timing range is 24 hours.
- Timer On. The machine turns on automatically at the

preset time.

- Timer Off. The machine turns off automatically at the preset time.
- Timer On/Off. The machine turns on automatically at the preset On Time, and then turns off automatically at the preset Off Time.
- Timer Off/On. The machine turns on automatically at the preset Off Time and then turns off automatically at the preset On Time.
- The timer does not change the unit operation mode. If the unit is off now, it does not start up immediately after the "timer off" function is set. When the setting time is reached, the timer LED switches off and the unit running mode remains unchanged.
- The timer uses relative time, not clock time

1.10 Sleep function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
 - When cooling, the temperature rises 1°C (to not higher than 30°C) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at low speed.
 - When heating, the temperature decreases 1°C (to not lower than 17°C) every hour. After 2 hours, the temperature stops decreasing and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- Entering shutdown, changing mode or speed setting cancels sleep mode..
- In this mode, the fan speed is forced into AUTO mode.

1.11 Auto-Restart function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings (not including the swing setting) and, in the case of a sudden power failure, will restore those setting automatically within 3 minutes after power returns.
- If the unit was in forced cooling mode, it will run in this mode for 30 minutes and turn to auto mode with temperature set to 24°C.
- If there is a power failure while the unit is running, the compressor starts 3 minutes after the unit restarts. If the unit was already off before the power failure, the compressor starts 1 minute after the unit restarts.

1.12 Refrigerant Leakage Detection

With this new technology, the display area will show “EC” when the outdoor unit detects refrigerant leakage.

1.13 Follow me(Optional)

- If you press “Follow Me” on the remote, the indoor unit will beep. This indicates the follow me function is active.
- Once active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the unit’s temperature setting.
- If the unit does not receive a signal for 7 minutes, the function turns off. The unit regulates temperature based on its own sensor and settings.
- Wired remote controller is prior to wireless remote controller.
- Use the water-level switch to control drain pump.
- The system checks the water level every 5 seconds.
 - When the A/C operates in cooling (including auto cooling) or forced cooling mode, the pump begins running immediately and continuously until cooling stops.
 - If the water level increases up to the control point, the LED displays an alarm code and the drain pump opens and continually monitors the water level. If the water level falls and LED alarm code is no longer displayed (drain pump close delay is 1 minute), the unit goes back into its last mode. Otherwise, the entire system (including the pump) stops and the LED displays an alarm again after 3 minutes.

1.14 Drain Pump Control (For Duct and Cassette)

- Use the water-level switch to control drain pump.
- The system checks the water level every 5 seconds.
 - When the A/C operates in cooling (including auto cooling) or forced cooling mode, the pump begins running immediately and continuously until cooling stops.
 - If the water level increases up to the control point, the LED displays an alarm code and the drain pump opens and continually monitors the water level. If the water level falls and LED alarm code is no longer displayed (drain pump close delay is 1 minute), the unit goes back into its last mode. Otherwise, the entire system (including the pump) stops and the LED displays an alarm again after 3 minutes.

1. Maintenance

1.1 First Time Installation Check

Air and moisture trapped in the refrigerant system affects the performance of the air conditioner by:

- Increasing pressure in the system.
- Increasing the operating current.
- Decreasing the cooling or heating efficiency.
- Congesting the capillary tubing due to ice build-up in the refrigerant circuit.
- Corroding the refrigerant system.

To prevent air and moisture from affecting the air conditioner’s performance, the indoor unit, as well as the pipes between the indoor and outdoor unit, must be leak tested and evacuated.

Leak test (soap water method)


Use a soft brush to apply soapy water or a neutral liquid detergent onto the indoor unit connections and outdoor unit connections. If there is gas leakage, bubbles will form on the connection.

Air purging with vacuum pump

Maintenance and Disassembly

Contents

1.	Maintenance	26
1.1	First Time Installation Check	26
1.2	Refrigerant Recharge	28
1.3	Re-Installation	29
1.3.1	Indoor Unit	29
1.3.2	Outdoor Unit	31
2.	Disassembly	33
2.1	Indoor Unit.....	33
2.2	Outdoor Unit.....	60




Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
 - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
 - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
 - If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
 - b. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backwards, check whether there is gas leakage.

-
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
 7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valve.

1.2 Refrigerant Recharge



Prior to recharging the refrigerant, confirm the additional amount of refrigerant required using the following table:

Models	Standard length	Max. elevation	Max. length	Additional refrigerant
18k	5m (16.4ft)	15m (49.2ft)	25m (82ft)	30g/m (0.32oz/ft)
24k	5m (16.4ft)	15m (49.2ft)	25m (82ft)	65g/m (0.69oz/ft)
36k	5m (16.4ft)	20m (65.6ft)	30m (98.4ft)	65g/m (0.69oz/ft)
48k&60k	5m (16.4ft)	30m (98.4ft)	50m (164ft)	65g/m (0.69oz/ft)


Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
If the refrigerant is R410A, invert the cylinder to ensure a complete liquid charge.
4. Partially open the Handle Lo manifold valve.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
6. Place the charging cylinder onto an electronic scale and record the starting weight.
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode and charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately.
10. Mount the caps of service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18N.m.
12. Check for gas leakage.

1.3 Re-Installation

1.3.1 Indoor Unit


Collecting the refrigerant into the outdoor unit



Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the charge hose with the push pin of Handle Lo to the 3-way valve's gas service port.
3. Open the Handle Lo manifold valve to purge air from the charge hose for 5 seconds and then close it quickly.
4. Close the 2-way valve.
5. Operate the air conditioner in cooling mode. Cease operations when the gauge reaches 0.1 MPa (14.5 Psi).
6. Close the 3-way valve so that the gauge rests between 0.3 MPa (43.5 Psi) and 0.5 MPa (72.5 Psi).
7. Disconnect the charge set and mount the caps of service port and 2- and 3-way valves.
8. Use a torque wrench to tighten the caps to a torque of 18N.m.
9. Check for gas leakage.

Air purging with vacuum pump




Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect another charge hose to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
 - c. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
 - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
 - d. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backwards, check whether there is gas leakage.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valve.

1.3.2 Outdoor Unit


Evacuation for the whole system



Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the vacuum pump to the 3-way valve's service port.
3. Evacuate the system for approximately one hour. Confirm that the compound meter indicates -0.1 MPa (14.5Psi).
4. Close the valve (Low side) on the charge set and turn off the vacuum pump. Wait for five minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check whether there is gas leakage.
5. Disconnect the charge hose from the vacuum pump.
6. Mount the caps of service port and 2- and 3-way valves.
7. Use a torque wrench to tighten the caps to a torque of 18N.m.

Refrigerant charging



Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Slightly connect the Handle Lo charge hose to the 3-way service port.
3. Connect the charge hose to the valve at the bottom of the cylinder.
If the refrigerant is R410A, invert the cylinder to ensure a complete liquid charge.
4. Partially open the Handle Lo manifold valve.
5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
6. Place the charging cylinder onto an electronic scale
7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
8. Operate the air conditioner in cooling mode and charge the system with liquid refrigerant.
9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately..
10. Mount the caps of service port and 2- and 3-way valves.
11. Use a torque wrench to tighten the caps to a torque of 18N.m.
12. Check for gas leakage.

Note: 1. Mechanical connectors used indoors shall comply with local regulations.



2. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.

2. Disassembly

2.1 Indoor unit



2.1.1 Ceiling&Floor

1. Front Panel

Procedure	Illustration
<p>1) Remove the 2 screws of return air grille subassembly and release the 2 hooks. (see CJ_CF_001)</p>	 <p>CJ_CF_001</p>
<p>2) Release the 2 hooks for each filter, and then pull up the filter. (see CJ_CF_002)</p>	 <p>CJ_CF_002</p>



Note: This section is for reference only. Actual unit appearance may vary.

2. Electrical parts (Antistatic gloves must be worn.)



Procedure	Illustration
<p>1) Remove 4 screws of the cover of electronic control box and then remove the cover. (see CJ_CF_003)</p>	 <p>CJ_CF_003</p>
<p>2) Disconnect the connectors and then remove the main control board. (see CJ_CF_004)</p>	 <p>CJ_CF_004</p>

Note: This section is for reference only. Actual unit appearance may vary.


3. Fan motor and fan

Procedure	Illustration
1) Remove the fix screw of supporting board. (see CJ_CF_005)	 <p data-bbox="957 996 1093 1041">CJ_CF_005</p>
2) Remove the screws of fan motor support and then remove the screw of ground wire. (see CJ_CF_006)	 <p data-bbox="957 1668 1093 1713">CJ_CF_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Remove the two screws of the fan motor shaft. (see CJ_CF_007)</p>	 <p>CJ_CF_007</p>
<p>4) Release the hooks of the volute shell and then pull up it. (see CJ_CF_008)</p>	 <p>CJ_CF_008</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>5) Remove the fixing screws of fan (3 screws). (see CJ_CF_009)</p>	 <p>CJ_CF_009</p>

Note: This section is for reference only. Actual unit appearance may vary.



4. Evaporator

Procedure	Illustration
<p>1) Remove the screws of left and right panel and then push it in the direction shown in the figure to move it. (see CJ_CF_010)</p>	 <p style="text-align: center;">CJ_CF_010</p>
<p>2) Remove the screws of the front panel(9 screws). (see CJ_CF_011)</p>	 <p style="text-align: center;">CJ_CF_011</p>




Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>3) Remove the 1 screw of the water collector. (see CJ_CF_012)</p>	 <p style="text-align: center;">CJ_CF_012</p>
<p>4) Remove the 4 screws of board and then remove it. (see CJ_CF_013)</p>	 <p style="text-align: center;">CJ_CF_013</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>5) Remove the screws of the pipe clamp board. (see CJ_CF_014)</p>	 <p>CJ_CF_014</p>
<p>6) Pull up the temperature sensor. (see CJ_CF_015)</p>	 <p>CJ_CF_015</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>7) Remove the screws of the front evaporator support. (5 screws) (see CJ_CF_016)</p>	 <p style="text-align: center;">CJ_CF_016</p>
<p>8) Remove the screws of the rear evaporator support then pull out the evaporator. (4 screws) (see CJ_CF_017)</p>	 <p style="text-align: center;">CJ_CF_017</p>
<p>9) Remove 2 screws and Remove step motor. (see CJ_CF_018)</p>	 <p style="text-align: center;">CJ_CF_018</p>

Note: This section is for reference only. Actual unit appearance may vary.



5. Display Board

Procedure	Illustration
<p>1) Remove 2 screws of display board and remove the display. (see CJ_CF_019)</p>	 <p>CJ_CF_019</p>



Note: This section is for reference only. Actual unit appearance may vary.

2.1.2 A6 Duct


1. Electrical parts (Antistatic gloves must be worn.)

Procedure	Illustration
<p>1) Remove 5 screws of the cover of electronic control box and then remove the cover. (see CJ_A6_001)</p>	 <p>CJ_A6_001</p>
<p>2) Remove the 2 screws of the electronic control box. Then release the 2 hooks of the main control board. (see CJ_A6_002)</p>	 <p>CJ_A6_002</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Disconnect the connectors and then remove the front main control board. (see CJ_A6_003)</p>	 <p style="text-align: center;">CJ_A6_003</p>
<p>4) Turn over the electronic control box. Disconnect the connectors and remove the 2 screws of rear main control board. (see CJ_A6_004)</p>	 <p style="text-align: center;">CJ_A6_004</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>5) Remove 2 screws of reactor and remove the reactor. (see CJ_A6_005)</p>	 <p>The illustration shows a hand using a screwdriver to remove two screws from a rectangular reactor component. The reactor is mounted on a metal frame. Several screws and washers are shown floating around the reactor, indicating they have been removed. The reactor is connected to a complex assembly of pipes and hoses on the left side of the frame.</p> <p>CJ_A6_005</p>

Note: This section is for reference only. Actual unit appearance may vary.

2. Fan motor and fan



Procedure	Illustration
<p>1) Remove 10 screws of the top cover and then remove the top cover. (see CJ_A6_006)</p>	 <p>CJ_A6_006</p>
<p>2) Release the 8 hooks of volute shell. (see CJ_A6_007)</p>	 <p>CJ_A6_007</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Remove the fixing screws of fan (2 screws). (see CJ_A6_008)</p>	 <p>CJ_A6_008</p>

Note: This section is for reference only. Actual unit appearance may vary.

3. Evaporator

Procedure	Illustration
<p>1) Remove 9 Screws of the water collector and remove the water collector. (see CJ_A6_009)</p>	 <p>CJ_A6_009</p>
<p>2) Remove the screws of the pipe clamp board and the left side board (3 for the pipe clamp and 9 for left side board). (see CJ_A6_010)</p>	 <p>CJ_A6_010</p>



Note: Remove the front panel (refer to 1. Front panel) before disassembling electrical parts.

Procedure	Illustration
<p>3) Remove the 2 fixing screws of the evaporator support and then pull up the temperature sensor. (see CJ_A6_011)</p>	 <p style="text-align: center;">CJ_A6_011</p>
<p>4) Remove the fixing screw of the evaporator and then remove it. (see CJ_A6_012)</p>	 <p style="text-align: center;">CJ_A6_012</p>


Note: This section is for reference only. Actual unit appearance may vary.

2.1.3 Cassette

1. Front Panel and Display Board



Procedure	Illustration
<p>1) Release the 2 hooks and open the panel. (see CJ_CASSETTE_001)</p>	 <p>CJ_CASSETTE_001</p>
<p>2) Pull up the filter. (see CJ_CASSETTE_002)</p>	 <p>CJ_CASSETTE_002</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>3) Disconnect the connectors and release the panel. (see CJ_CASSETTE_003)</p>	 <p data-bbox="901 936 1126 965">CJ_CASSETTE_003</p>

Note: This section is for reference only. Actual unit appearance may vary.

2. Electrical parts (Antistatic gloves must be worn.)



Procedure	Illustration
<p>1) Remove the 2 screws and remove the cover of electronic control box. (see CJ_CASSETTE_004)</p>	 <p>CJ_CASSETTE_004</p>
<p>2) Remove the 2 screws of the main control board. (see CJ_CASSETTE_005)</p>	 <p>CJ_CASSETTE_005</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>3) Disconnect the connectors and then remove the main control board. (see CJ_CASSETTE_006)</p>	 <p>CJ_CASSETTE_006</p>



Note: This section is for reference only. Actual unit appearance may vary.

3. Display Board

Procedure	Illustration
<p>1) Remove the 2 screws of display board and remove the display board. (see CJ_CASSETTE_007)</p>	 <p>CJ_CASSETTE_007</p>
<p>2) Turn over the display board, prise the 6 hooks with a flat screwdriver as shown in the figure. (see CJ_CASSETTE_008)</p>	 <p>CJ_CASSETTE_008</p>



Note: This section is for reference only. Actual unit appearance may vary.

4. Fan motor and fan



Procedure	Illustration
<p>1) Remove the fixing nut of the fan and then pull up the fan. (see CJ_CASSETTE_009)</p>	 <p>CJ_CASSETTE_009</p>
<p>2) Remove the 2 screws of fixing board and the 4 fixing nuts of fan motor. (see CJ_CASSETTE_010)</p>	 <p>CJ_CASSETTE_010</p>

Note: This section is for reference only. Actual unit appearance may vary.

5. Evaporator



Procedure	Illustration
<p>1) Remove the 4 screws of the panel and pull up the panel. (see CJ_CASSETTE_011)</p>	 <p>CJ_CASSETTE_011</p>
<p>2) Remove the 2 screws of seal boardpipe clamp board. (see CJ_CASSETTE_012)</p>	 <p>CJ_CASSETTE_012</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>3) Remove the 4 screws of the evaporator support and then remove it. (see CJ_CASSETTE_013)</p>	 <p style="text-align: center;">CJ_CASSETTE_013</p>
<p>4) Remove the 2 screws of the evaporator fixing bracket and then remove it. (see CJ_CASSETTE_014)</p>	 <p style="text-align: center;">CJ_CASSETTE_014</p>

Note: This section is for reference only. Actual unit appearance may vary.

6. Water Pump

Procedure	Illustration
<p>1) Take off the fasten belt of the water pump. (see CJ_CASSETTE_015)</p>	 <p>CJ_CASSETTE_015</p>
<p>2) Pinch the metal wire in the direction shown in the figure to release it. (see CJ_CASSETTE_016)</p>	 <p>CJ_CASSETTE_016</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>3) Remove the 3 fixing screws and then remove the water pump. (see CJ_CASSETTE_017)</p>	 <p>CJ_CASSETTE_017</p>

Note: This section is for reference only. Actual unit appearance may vary.



2.2 Outdoor unit

1. Panel Plate


YUFE18BYTM-MO-X, YUFE24BYTM-MO-X, MOCA30U-18HN1-NB8, MOCA30U-24HN1-NB8

Procedure	Illustration
<p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (3 screws) (see CJ_CA30_001).</p>	 <p>For US models (3 screws)</p> <p>CJ_CA30_001</p>
<p>3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_CA30_002).</p>	 <p>Top Cover</p> <p>CJ_CA30_002</p>



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>4) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ_CA30_003).</p>	 <p>CJ_CA30_003</p>
<p>5) Remove the screws of water collecting cover and then remove the water collecting cover (1 screw) (see CJ_CA30_004).</p>	 <p>CJ_CA30_004</p>



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>6) Remove the screws of the right panel and then remove the right panel (6 screws) (see CJ_CA30_005).</p>	 <p>The illustration shows a hand using a screwdriver to remove screws from the right panel of a unit. The unit is shown in a three-quarter view, with the right panel being the focus. A dashed line points to the right panel, which is labeled "Right Panel". The unit has a control panel on the left side with several buttons and a dial. The right panel is a large, rectangular panel with a textured surface. There are six screws shown being removed from the right panel. The unit is labeled "CJ_CA30_005" at the bottom.</p>



Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (2 screws) (see CJ_D30_001).</p>	 <p>For US models (3 screws)</p> <p>CJ_D30_001</p>
<p>3) Remove the screws of the top cover and then remove the top cover (4 screws). Two of the screws is located underneath the big handle (see CJ_D30_002).</p>	 <p>Top Cover</p> <p>CJ_D30_002</p>

Note: This section is for reference only. Actual unit appearance may vary.




Procedure	Illustration
<p>4) Remove the screws of the front right panel and then remove the front right panel (2 screws) (see CJ_D30_003).</p>	 <p>CJ_D30_003</p>
<p>5) Remove the screws of the front panel and then remove the front panel (9 screws) (see CJ_D30_004).</p>	 <p>Front Panel</p> <p>CJ_D30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>6) Remove the screws of water collecting cover and then remove the water collecting cover (2 screw) (see CJ_D30_005).</p>	 <p>Water Collecting Cover</p> <p>CJ_D30_005</p>
<p>7) Remove the screws of the right panel and then remove the right panel (8 screws) (see CJ_D30_006).</p>	 <p>Right Panel</p> <p>CJ_D30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.



YUFE48BYTM-MS-1, YUFE48BYSM-MS-1, MOE30U-48HN1-NB8, YUFE60BYTM-MS-1, YUFE60BYSM-MS-1, MOE30U-60HN1-NB8

Procedure	Illustration
<p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (2 screws) (see CJ_E30_001).</p>	 <p style="text-align: center;">CJ_E30_001</p>
<p>3) Remove the screws of the top cover and then remove the top cover (4 screws). Two of the screws is located underneath the big handle (see CJ_E30_002).</p>	 <p style="text-align: center;">CJ_E30_002</p>
<p>4) Remove the screws of water collecting cover and then remove the water collecting cover (2 screw) (see CJ_E30_003).</p>	 <p style="text-align: center;">CJ_E30_003</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>5) Remove the screws of the front right panel and then remove the front right panel (2 screws) (see CJ_E30_004).</p>	 <p>CJ_E30_004</p>

Note: This section is for reference only. Actual unit appearance may vary.



Procedure	Illustration
<p>6) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ_E30_005).</p>	 <p style="text-align: center;">CJ_E30_005</p>
<p>7) Remove the screws of the right panel and then remove the right panel (10 screws) (see CJ_E30_006).</p>	 <p style="text-align: center;">CJ_E30_006</p>

Note: This section is for reference only. Actual unit appearance may vary.


2. Fan disassembly

Note: Remove the panel plate and (refer to 1. Panel plate) before disassembling fan.



YUFE18BYTM-MO-X, YUFE24BYTM-MO-X, YUFE36BYTM-MO-X

Procedure	Illustration
<p>1) Remove the nut securing the fan with a spanner (see CJ_ODU_001).</p> <p>2) Remove the fan.</p>	 <p style="text-align: center;">CJ_ODU_001</p>
<p>3) Disconnect the connectors for fan motor. (Blue wire, yellow wire, red wire, brown wire and black wire. The blue wire and red wire are on the capacitor. The black wire connects with terminal 4.) (see CJ_ODU_002)</p>	 <p style="text-align: center;">CJ_ODU_002</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
<p>4) Remove the fixing screws of the fan motor (4 screws) (see CJ_ODU_003).</p> <p>5) Remove the fan motor.</p>	 <p>CJ_ODU_003</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>1) Remove the nut securing the fan with a spanner (see CJ_ODU_004).</p> <p>2) Remove the fan.</p>	 <p style="text-align: center;">D-cut</p> <p style="text-align: center;">CJ_ODU_004</p>
<p>3) Disconnect the connectors for fan motor. (see CJ_ODU_005)</p>	 <p style="text-align: center;">CJ_ODU_005</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure

- 4) Remove the fixing screws of the fan motor (4 screws) (see CJ_ODU_006).
- 5) Remove the fan motor.


Illustration



CJ_ODU_006

Note: This section is for reference only. Actual unit appearance may vary.

YUFE48BYTM-MS-1, YUFE48BYSM-MS-1, MOE30U-48HN1-NB8, YUFE60BYTM-MS-1, YUFE60BYSM-MS-1, MOE30U-60HN1-NB8


Procedure	Illustration
<p>1) Remove the nut securing the fan with a spanner (see CJ_ODU_007).</p> <p>2) Remove the fan.</p> <p>3) Disconnect the connectors for fan motor from the terminal. (see CJ_ODU_007)</p> <p>4) Remove the fixing screws of the fan motor (4 screws) (see CJ_ODU_008).</p> <p>5) Remove the fan motor.</p>	 <p>The illustration is divided into two parts. The top part, labeled 'CJ_ODU_007', shows a hand using a spanner to remove a nut from a fan. A circular inset shows a close-up of the fan's hub with a 'D-cut' indicated. The bottom part, labeled 'CJ_ODU_008', shows a hand using a screwdriver to remove screws from the fan motor. A circular inset shows a close-up of the fan motor being removed from its housing, with an arrow indicating the direction of removal. A label 'Fan Motor' points to the motor in the main illustration.</p>

Note: This section is for reference only. Actual unit appearance may vary.

3. Electrical parts


Note: Remove the panel plate and fan assembly (refer to 1. Panel plate and 2. Fan assembly) before disassembling electrical parts.

YUFE18BYTM-MO-X, YUFE24BYTM-MO-X, YUFE36BYTM-MO-X

Procedure	Illustration
<ol style="list-style-type: none">1) Remove the two screws fixed the electronic control board (see CJ_ODU_009).2) Disconnect the wires connected to the compressor. (Black wire connects with terminal 1, blue wire and red wire connect with the compressor capacitor) (see CJ_ODU_009)3) Disconnect the wires connected to 4-way valve. (Blue wires on terminal 2&3) (see CJ_ODU_009)4) Remove the fixing screw of the compressor capacitor, then pull it out (see CJ_ODU_009)5) Remove the electrical parts (see CJ_ODU_009)	 <p style="text-align: center;">CJ_ODU_009</p>



Note: This section is for reference only. Actual unit appearance may vary.

MOCA30U-18HN1-NB8, MOCA30U-24HN1-NB8 , MOD30U-36HN1-NB8, YUFE36BYSM-MO-1



Procedure	Illustration
<p>6) Disconnect the power transformer (see CJ_ODU_010)</p> <p>7) Disconnect the wires connected to terminals. (see CJ_ODU_010)</p> <p>8) Disconnect the wires connected to contactor. (see CJ_ODU_010)</p> <p>9) Disconnect the wires connected to T3/T4 sensor. (see CJ_ODU_010)</p>	 <p>The diagram shows a control board with various components. Labels include T3 (Black) and T4 (White) at the top, Fan Motor, Contactor, Power Transformer, and Terminal at the bottom. An arrow points to the terminal block on the right side of the board.</p> <p style="text-align: center;">CJ_ODU_010</p>

Note: This section is for reference only. Actual unit appearance may vary.

YUFE48BYTM-MS-1, YUFE48BYSM-MS-1, MOE30U-48HN1-NB8, YUFE60BYTM-MS-1, YUFE60BYSM-MS-1, MOE30U-60HN1-NB8

Procedure	Illustration
<p>10) Disconnect the wires connected to the transformer. (see CJ_ODU_011)</p> <p>11) Disconnect the wires connected to high/low pressure switch. (see CJ_ODU_011)</p> <p>12) Disconnect the wires connected to indoor unit. (see CJ_ODU_011)</p> <p>13) Disconnect the wires connected to AC contactor. (see CJ_ODU_011)</p>	 <p style="text-align: center;">CJ_ODU_011</p>
<p>14) Remove the screws of the capacitor and then remove it (1screw for each capacitor). (see CJ_ODU_012)</p>	 <p style="text-align: center;">CJ_ODU_012</p>

Note: This section is for reference only. Actual unit appearance may vary.


Procedure	Illustration
<p>15) Remove the 1 screw of the AC contactor and then remove it. (see CJ_ODU_013)</p>	 <p style="text-align: center;">CJ_ODU_013</p>
<p>16) Remove 2 screws of the transformer and then remove it. (see CJ_ODU_014)</p>	 <p style="text-align: center;">CJ_ODU_014</p>

Note: This section is for reference only. Actual unit appearance may vary.

4. Sound blanket

⚠ WARNING: Recover refrigerant from the refrigerant circuit before remove the compressor.

Note: Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling sound blanket.


Procedure	Illustration
1) Remove the sound blanket (side and top) (see CJ_ODU_015).	 <p data-bbox="933 1064 1101 1097">CJ_ODU_015</p>

Note: This section is for reference only. Actual unit appearance may vary.

5. Four-way valve (For heat pump models)

⚠ WARNING: Recover refrigerant from the refrigerant circuit before remove the four-way valve.

Note: Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling four-way valve.



Procedure	Illustration
<ol style="list-style-type: none">1) Heat up the brazed parts and then detach the the four-way valve and the pipe (see CJ_ODU_016).2) Remove the four-way valve assembly with pliers.	 <p data-bbox="957 1646 1125 1691">CJ_ODU_016</p>

Note: This section is for reference only. Actual unit appearance may vary.

6. Compressor

⚠ WARNING: Recover refrigerant from the refrigerant circuit before remove the compressor.


Note: Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling compressor.

Procedure	Illustration
<p>1) Remove the flange nut of terminal cover and remove the terminal cover (see CJ_ODU_017).</p>	 <p>The diagram shows a top-down view of the compressor assembly. A dashed line points to a flange nut on the terminal cover. The label 'Terminal Cover' is positioned to the left of the diagram.</p> <p style="text-align: center;">CJ_ODU_017</p>
<p>2) Disconnect the connectors (see CJ_ODU_018).</p>	 <p>The diagram shows a close-up of a hand using a tool to disconnect a connector from the compressor's electrical terminals. An upward-pointing arrow indicates the direction of the tool's movement.</p> <p style="text-align: center;">CJ_ODU_018</p>

Note: This section is for reference only. Actual unit appearance may vary.

Procedure	Illustration
-----------	--------------


3) Remove the hex nuts and washers securing the compressor, located on the bottom plate (see CJ_ODU_019).



CJ_ODU_019

4) Heat up the brazed parts and then remove the the discharge pipe and the suction pipe (see CJ_ODU_020).

5) Lift the compressor from the base pan assembly with pliers.



CJ_ODU_020

Note: This section is for reference only. Actual unit appearance may vary.

Troubleshooting

Contents

1.	Safety Caution	84
2.	General Troubleshooting	85
2.1	Error Display (Indoor Unit).....	85
2.2	Error Display (Outdoor Unit).....	87
3.	Error Diagnosis and Troubleshooting Without Error Code.....	88
3.1	Remote maintenance.....	88
3.2	Field maintenance	89
4.	Quick Maintenance by Error Code.....	94
5.	Troubleshooting by Error Code.....	95
5.1	Common Check Procedures.....	95
5.2	Open circuit or short circuit of T1 or T2 temperature sensor diagnosis and solution	96
5.3	EEPROM parameter error diagnosis and solution.....	97
5.4	Water level alarm malfunction diagnosis and solution	98
5.5	EC (Refrigerant Leakage Detection diagnosis and solution)	99
5.6	F0 (Communication malfunction between indoor unit and auto-lifting panel diagnosis and solution).....	100
5.7	F1 (Auto-lifting panel malfunction diagnosis and solution).....	101

Troubleshooting


Contents

5.8	Phase Sequence diagnosis and solution	102
5.9	Lack of Phase diagnosis and solution	103
5.10	Overload current protection diagnosis and solution.....	104
5.11	High temperature or protection of pressure diagnosis and solution	105


1. Safety Caution

WARNING

Electricity remains in capacitors even when the power supply is off.
Ensure the capacitors are fully discharged before troubleshooting.



For other models, connect discharge resistance (approx. 100Ω 40W) or a soldering iron plug between the positive and negative terminals of the electrolytic capacitor. The terminals are located on the bottom surface of the outdoor PCB.



Note: This picture is for reference only. Actual appearances may vary.

2. General Troubleshooting

2.1 Error Display (Indoor Unit)

When the indoor unit encounters a recognized error, the indicator light will flash in a corresponding series, the timer display may turn on or begin flashing, and an error code will be displayed. These error codes are described in the following table:

For Ceiling&floor type:

Operation lamp	Timer lamp	Defrosting lamp	Alarm lamp	Display	Error Information	Solution
OFF	FLASH	OFF	OFF	E2	Indoor room temperature sensor T1 is in open circuit or has short circuited	Page 96
FLASH	OFF	OFF	OFF	E3	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	Page 96
OFF	OFF	FLASH	OFF	E4	Condenser coil temperature sensor T3 is in open circuit or has short circuited (except for 18k/24k/36k cooling-only models)	Page 96
FLASH	FLASH	OFF	OFF	E7	Indoor unit EEPROM parameter error	Page 97
FLASH	OFF	OFF	FLASH	EC	Refrigerant leak detected	Page 99
OFF	OFF	OFF	FLASH	E8	Water level alarm malfunction	Page 98

For A6 Duct type:

Operation lamp flashes	Timer lamp	Display	Error Information	Solution
1 time	OFF	E0	Indoor unit EEPROM parameter error	Page 97
5 times	OFF	E4	Indoor room temperature sensor T1 is in open circuit or has short circuited	Page 96
6 times	OFF	E5	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	Page 96
7 times	OFF	EC	Refrigerant leak detected	Page 99
8 times	OFF	EE	Water level alarm malfunction	Page 98
3 times	ON	F2	Condenser coil temperature sensor T3 is in open circuit or has short circuited (except for 18k/24k/36k cooling-only models)	Page 96
11 times	ON	FR	Dual chips communication malfunction	-

For Super-slim cassette type:

Operation lamp	Timer lamp	Defrosting lamp	Alarm lamp	Display	Error Information	Solution
OFF	FLASH	OFF	OFF	E2	Indoor room temperature sensor T1 is in open circuit or has short circuited	Page 96
FLASH	OFF	OFF	OFF	E3	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	Page 96
OFF	OFF	FLASH	OFF	E4	Condenser coil temperature sensor T3 is in open circuit or has short circuited (except for 18k/24k/36k cooling-only models)	Page 96
FLASH	FLASH	OFF	OFF	E7	Indoor unit EEPROM parameter error	Page 97
OFF	OFF	OFF	FLASH	E8	Water level alarm malfunction	Page 98
FLASH	FLASH	FLASH	OFF	E9	Protection of Low pressure (only for 48k and 60k models)	Page 105
FLASH	OFF	OFF	FLASH	EC	Refrigerant leakage detection	Page 99
FLASH	OFF	FLASH	FLASH	F0	Communication malfunction between main PCB and up-down panel PCB	Page 100
OFF	FLASH	FLASH	FLASH	F1	Up-down panel malfunction	Page 101
OFF	ON	FLASH	FLASH	F2	Up-down panel is not closed	-

For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.

2.2 Error Display (Outdoor Unit) (except for 18k/24k/36k single phase cooling-only models)

LED1	LED2	LED3	Error Information	Solution
FLASH	OFF	OFF	Phase sequence	Page 102
FLASH	OFF	OFF	Lack of phase(A,B)	Page 103
OFF	OFF	OFF	Lack of phase(C)	Page 103
FLASH	FLASH	OFF	Protection of low pressure (only for 48k and 60k models)	Page 105
OFF	OFF	FLASH	Overload of current	Page 104
OFF	FLASH	FLASH	Open-circuit and short-circuit trouble of T3	Page 96
OFF	FLASH	OFF	protection of high pressure (only for 48k and 60k models)	Page 105
FLASH	FLASH	FLASH	High temperature protection of condenser	Page 105

3. Error Diagnosis and Troubleshooting Without Error Code

WARNING

Be sure to turn off unit before any maintenance to prevent damage or injury.

3.1 Remote maintenance

SUGGESTION: When troubles occur, please check the following points with customers before field maintenance.

	Problem	Solution
1	Unit will not start	Page 90-91
2	The power switch is on but fans will not start	Page 90-91
3	The temperature on the display board cannot be set	Page 90-91
4	Unit is on but the wind is not cold(hot)	Page 90-91
5	Unit runs, but shortly stops	Page 90-91
6	The unit starts up and stops frequently	Page 90-91
7	Unit runs continuously but insufficient cooling(heating)	Page 90-91
8	Cool can not change to heat	Page 90-91
9	Unit is noisy	Page 90-91

3.2 Field maintenance

	Problem	Solution
1	Unit will not start	Page 92-93
2	Compressor will not start but fans run	Page 92-93
3	Compressor and condenser (outdoor) fan will not start	Page 92-93
4	Evaporator (indoor) fan will not start	Page 92-93
5	Condenser (Outdoor) fan will not start	Page 92-93
6	Unit runs, but shortly stops	Page 92-93
7	Compressor short-cycles due to overload	Page 92-93
8	High discharge pressure	Page 92-93
9	Low discharge pressure	Page 92-93
10	High suction pressure	Page 92-93
11	Low suction pressure	Page 92-93
12	Unit runs continuously but insufficient cooling	Page 92-93
13	Too cool	Page 92-93
14	Compressor is noisy	Page 92-93
15	Horizontal louver can not revolve	Page 92-93

Possible causes of trouble	1.Remote Maintenance				Electrical Circuit				Refrigerant Circuit					
	Power failure	The main power tripped	Loose connections	Faulty transformer	The voltage is too high or too low	The remote control is powered off	Broken remote control	Dirty air filter	Dirty condenser fins	The setting temperature is higher/lower than the room's(cooling/heating)	The ambient temperature is too high/low when the mode is cooling/heating	Fan mode	SILENCE function is activated(optional function)	Frosting and defrosting frequently
Unit will not start	☆	☆	☆	☆										
Operation is erratic, unpredictable, or unit is unresponsive														
The temperature on the playboard cannot be setted						☆	☆							
Unit is on but the wind is not cold(hot)										☆	☆	☆		
Unit runs, but shortly stops					☆					☆	☆			
The unit startup and stop frequently					☆						☆			☆
Unit runs continuously but insufficient cooling(heating)								☆	☆	☆	☆		☆	
Cool can not change to heat														
Unit is noisy														
The unit emits a bad odor								☆						
Test method / remedy	Test voltage	Close the power switch	Inspect connections - tighten	Change the transformer	Test voltage	Replace the battery of the remote control	Replace the remote control	Clean or replace	Clean	Adjust the setting temperature	Turn the AC later	Adjust to cool mode	Turn off SILENCE function.	Turn the AC later

Others									
Check heat load						☆			Heavy load condition
Tighten bolts or screws		☆							Loosen hold down bolts and / or screws
Close all the windows and doors						☆			Bad airproof
Remove the obstacles						☆			The air inlet or outlet of either unit is blocked
Reconnect the power or press ON/OFF button on remote control to restart								☆	Interference from cell phone towers and remote boosters
Remove them								☆	Shipping plates remain attached

2.Field Maintenance		Electrical Circuit													
Possible causes of trouble	Possible causes of trouble														
	Power failure	Blown fuse or varistor	Loose connections	Shorted or broken wires	Safety device opens	Faulty thermostat / room temperature sensor	Wrong setting place of temperature sensor	Faulty transformer	Shorted or open capacitor	Faulty magnetic contactor for compressor	Faulty magnetic contactor for fan	Low voltage	Faulty stepping motor	Shorted or grounded compressor	Shorted or grounded fan motor
Unit will not start	☆	☆	☆	☆	☆			☆							
Compressor will not start but fans run				☆	☆				☆	☆				☆	
Compressor and condenser (outdoor) fan will not start				☆		☆				☆					
Evaporator (indoor) fan will not start				☆					☆		☆				☆
Condenser (Outdoor) fan will not start				☆		☆			☆		☆				☆
Unit runs, but shortly stops										☆		☆			
Compressor short-cycles due to overload										☆		☆			
High discharge pressure															
Low discharge pressure															
High suction pressure															
Low suction pressure															
Unit runs continuously but insufficient cooling															
Too cool						☆	☆								
Compressor is noisy															
Horizontal louver can not revolve			☆	☆									☆		
Test method / remedy	Test method / remedy														
	Test voltage	Inspect fuse type & size	Inspect connections - tighten	Test circuits with tester	Test continuity of safety device	Test continuity of thermostat / sensor & wiring	Place the temperature sensor at the central of the air inlet grille	Check control circuit with tester	Check capacitor with tester	Test continuity of coil & contacts	Test continuity of coil & contacts	Test voltage	Replace the stepping motor	Check resistance with meger tester	Check resistance with meger tester

Refrigerant Circuit												Others	
Replace the compressor												Compressor stuck	
Leak test												Shortage of refrigerant	
Replace restricted part												Restricted liquid line	
Clean or replace												Dirty air filter	
Clean coil												Dirty evaporator coil	
Check fan												Insufficient air through evaporator coil	
Change charged refrigerant volume												Overcharge of refrigerant	
Clean condenser or remove obstacle												Dirty or partially blocked condenser	
Purge, evacuate and recharge												Air or noncondensable gas in refrigerant cycle	
Remove obstruction to air flow												Short cycling of condensing air	
Remove obstruction in air or water flow												High temperature condensing medium	
Remove obstruction in air or water flow												Insufficient condensing medium	
Replace compressor												Broken compressor internal parts	
Test compressor efficiency												Inefficient compressor	
Replace valve												Expansion valve obstructed	
Replace valve												Expansion valve or capillary tube closed completely	
Replace valve												Leaking power element on expansion valve	
Fix feeler bulb												Poor installation of feeler bulb	
Check heat load												Heavy load condition	
Tighten bolts or screws												Loosen hold down bolts and / or screws	
Remove them												Shipping plates remain attached	
Choose AC of larger capacity or add the number of AC												Poor choices of capacity	
Rectify piping so as not to contact each other or with external plate												Contact of piping with other piping or external plate	

4. Quick Maintenance by Error Code

If you do not have the time to test whether specific parts are faulty, you can directly change the required parts according to the error code.

You can find the parts to replace by error code in the following table.

For ceiling&floor type and super-slim cassette type:

Part requiring replacement	Error Code								
	E2	E3	E4	E7	E8	E9	EC	F0	F1
Indoor PCB	✓	✓	✓	✓	✓	✓	x	✓	x
T1 sensor	✓	x	x	x	x	x	x	x	x
T2 Sensor	x	✓	x	x	x	x	✓	x	x
T3 Sensor	x	x	✓	x	x	x	x	x	x
Additional refrigerant	x	x	x	x	x	✓	✓	x	x
Water-level switch	x	x	x	x	✓	x	x	x	x
Water pump	x	x	x	x	✓	x	x	x	x
Louver motor	x	x	x	x	x	x	x	x	✓
Up-down panel PCB	x	x	x	x	x	x	x	x	✓

For A6 Duct type:

Part requiring replacement	Error Code						
	E0	E4	E5	EE	EC	F2	FR
Indoor PCB	✓	✓	✓	✓	x	✓	✓
T1 sensor	x	✓	x	x	x	x	x
T2 Sensor	x	x	✓	x	✓	x	x
T3 Sensor	x	x	x	x	x	✓	x
Additional refrigerant	x	x	x	x	✓	x	x
Water-level switch	x	x	x	✓	x	x	x
Water pump	x	x	x	✓	x	x	x

5. Troubleshooting by Error Code

5.1 Common Check Procedures

5.1.1 Temperature Sensor Check

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.

Temperature Sensors.

Room temp.(T1) sensor,

Indoor coil temp.(T2) sensor,

Outdoor coil temp.(T3) sensor,

Outdoor ambient temp.(T4) sensor.

Measure the resistance value of each winding by using the multi-meter.



5.2 E2/E3/E4 for ceiling&floor type and super slim cassette type&E4/E5/F2 for A6 duct type (Open circuit or short circuit of temperature sensor diagnosis and solution)

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.

Recommended parts to prepare:

- Wiring mistake
- Faulty sensor
- Faulty PCB

Troubleshooting and repair:




5.3 E7 for ceiling&floor type and super slim cassette type&E0 for A6 duct type (EEPROM parameter error)

Description: Indoor PCB main chip does not receive feedback from EEPROM chip.


Recommended parts to prepare:

- Indoor PCB
- Troubleshooting and repair:



Remarks:

The location of the EEPROM chip on the indoor PCB is shown in the following image:



Note: These images are for reference only.


5.4 E8 for ceiling&floor type and super slim cassette type&EE for A6 duct type (Water level alarm malfunction diagnosis and solution)

Description: The water level switch is at the max. position to shut down the unit.

Recommended parts to prepare:

- Faulty drain pump (for units with drain pump)
- Installation mistake of water level switch (for units with drain pump)
- Short-circuit jumper is missing or broken (for units without drain pump)
- Faulty indoor PCB

Troubleshooting and repair:



5.5 EC (Refrigerant Leakage Detection diagnosis and solution)

Description: Define the evaporator coil temp.T2 of the compressor just starts running as Tcool.


If the following occurs 3 times, the display shows "EC" and the unit switches off:

In the first 8 minutes after the compressor starts up, if $T2 < T_{cool} - 2^{\circ}\text{C}$ is not maintained for 4 seconds and compressor running frequency is not higher than 50Hz for 3 minutes.

Recommended parts to prepare:

- Faulty T2 sensor
- Faulty compressor
- Faulty capacitor of compressor
- Faulty indoor PCB
- System problems, such as leakage or blockages
- Faulty capacitor of fan motor
- Faulty outdoor fan

Troubleshooting and repair:




5.6 F0(Communication malfunction between indoor unit and auto-lifting panel diagnosis and solution)

Description: Indoor PCB does not get the feedback from the PCB of auto-lifting panel.

Recommended parts to prepare:

- Wiring mistake between indoor PCB and auto-lifting panel
- Faulty PCB of auto-lifting panel
- Faulty indoor PCB

Troubleshooting and repair:



5.7 F1(Auto-lifting panel malfunction diagnosis and solution)

Description: Indoor PCB does not get the right close position from the PCB of auto lifting-panel when the panel motor stops

Recommended parts to prepare:

- Wiring mistake between indoor PCB and auto-lifting panel
- Faulty PCB of auto-lifting panel
- Faulty louver motor

Troubleshooting and repair:




5.8 Phase sequence error diagnosis and solution

Description: Outdoor PCB detects the wrong phase sequence of 3-phase power supply.

Recommended parts to prepare:

- Wiring mistake of 3-phase power supply
- Faulty outdoor PCB

Troubleshooting and repair:




5.9 Lack of Phase diagnosis and solution

Description: Outdoor PCB detects the voltage of one or two phase are very low.

Recommended parts to prepare:

- Problems of 3-phase power supply
- Wiring mistake of 3-phase power supply
- Faulty outdoor PCB

Troubleshooting and repair:




5.10 Overload current protection diagnosis and solution

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Recommended parts to prepare:

- Power supply problems.
- System blockage
- Faulty PCB
- Wiring mistake
- Compressor malfunction

Troubleshooting and repair:




5.11 High temperature or protection of pressure diagnosis and solution

Description: The High pressure switch detects a ultra high pressure or the Low pressure switch detects a ultra low switch, which could damage the system.

Recommended parts to prepare:

- Bad wiring of the pressure switches
- Faulty pressure switches
- Refrigeration system is over load or blocked or lack of refrigerant

Troubleshooting and repair:





Contents

i)	Temperature Sensor Resistance Value Table for T1, T2, T3, and T4 (°C – K) ..	112
i)	Pressure On Service Port	113

i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231


ii) Pressure On Service Port(R410A)

Cooling chart:

°F(°C)	ODT		0(-17)	5(-15)	15 (9.44)	45 (7.22)	75 (23.89)	85 (29.44)	95 (35)	105 (40.56)	115 (46.11)	120 (48.89)
	IDT											
BAR	70/59		6.4	6.5	7.3	8.0	8.2	7.8	8.1	8.6	10.1	10.6
BAR	75/63		6.7	6.8	7.9	8.6	8.6	8.3	8.7	9.1	10.7	11.2
BAR	80/67		7.1	7.2	8.5	9.5	9.3	8.9	9.1	9.6	11.2	11.9
BAR	90/73		7.7	7.8	9.6	10.5	10.3	9.5	10.0	10.6	12.4	13.0

°F(°C)	ODT		0(-17)	5(-15)	15 (9.44)	45 (7.22)	75 (23.89)	85 (29.44)	95 (35)	105 (40.56)	115 (46.11)	120 (48.89)
	IDT											
PSI	70/59		93	94	106	116	119	113	117	125	147	154
PSI	75/63		97	99	115	125	124	120	126	132	155	162
PSI	80/67		103	104	123	138	135	129	132	140	162	173
PSI	90/73		112	113	139	152	149	138	145	154	180	189

°F(°C)	ODT		0(-17)	5(-15)	15 (9.44)	45 (7.22)	75 (23.89)	85 (29.44)	95 (35)	105 (40.56)	115 (46.11)	120 (48.89)
	IDT											
MPA	70/59		0.64	0.65	0.73	0.8	0.82	0.78	0.81	0.86	1.01	1.06
MPA	75/63		0.67	0.68	0.79	0.86	0.86	0.83	0.87	0.91	1.07	1.12
MPA	80/67		0.71	0.72	0.85	0.95	0.93	0.89	0.91	0.96	1.12	1.19
MPA	90/73		0.77	0.78	0.96	1.05	1.03	0.95	1	1.06	1.24	1.3




Heating chart:

°F(°C)	ODT		57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/- 10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
	IDT								
BAR	55		30.3	28.5	25.3	22.8	20.8	18.5	16.5
BAR	65		32.5	30.0	26.6	25.4	23.3	20.5	19.0
BAR	75		33.8	31.5	27.8	26.3	24.9	21.5	20.0

°F(°C)	ODT		57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/- 10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
	IDT								
PSI	55		439	413	367	330	302	268	239
PSI	65		471	435	386	368	339	297	276
PSI	75		489	457	403	381	362	312	290

°F(°C)	ODT		57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/- 10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
	IDT								
MPA	55		3.03	2.85	2.53	2.28	2.08	1.85	1.65
MPA	65		3.25	3.00	2.66	2.54	2.33	2.05	1.90
MPA	75		3.38	3.15	2.78	2.63	2.49	2.15	2.00





©2019 Johnson Controls, Inc.

www.johnsoncontrols.com

Form: MYFETM-MOW1-190830

Johnson Controls reserve the right to change product features without prior notice.